


## KRAIBURG PORCA fix



- mat must be secured so that it cannot slide out of place (e.g. long screw, slat anchors fitting for the floor, ...)
- as a rule, 2 fixations in the middle of the mat will suffice
- detaching and cleaning are not hindered



Because there are so many different grids in the farrowing crate we can't sell one fix solution.

Please ask your grid manufacturer!



**Tip:** use a long screw with a washer secured with a nut from underneath. So, the mat can simply be plugged onto the grid.

### Example:

